MANAGE YOUR HOME COMFORT

A guide to
***peaksaver* PLUS**™
and your new
programmable
thermostat

hydro one

Partners in Powerful Communities

Accessing your thermostat online

You can access your thermostat from anywhere you have Internet access.

Logging in to the *peaksaver* PLUS™ website

1. Go to **www.controlyourthermostat.ca**
2. Enter your username and password.

   Username:
   Your username is your Hydro One account number. Enter it with no leading zeros (0) or dashes.

   Password:
   Your password is the first six letters of your last name, without spaces or capitals. If your last name is less than six letters your password will be shorter. You can change your password after you log in.

Record your username and password here for easy future reference:	
USERNAME:	
PASSWORD:	

3. Click "Submit." This takes you to your General Account page.

REMOTE WEB ACCESS



General Account Page

This is where you access menus to manage your *peaksaver* PLUS™ programs:

Account

- View General Account Page

Thermostat

- View and change thermostat schedules
- Temporarily change thermostat settings (Manual)
- View saved sechedules

Programs

- View control history

Questions

- Locate contact information
- Review Frequently Asked Questions (FAQs) and Terms and Conditions

Administration

- Change username and password

peaksaver PLUS™
hydro one
Logout
Account
General
Thermostat
123456789
Programs
Control History
Questions
Contact Us
FAQ
Administration
Change Login
Welcome to peaksaver PLUS™
hydro one Brampton
hydro one
Thank you for participating in peaksaver PLUS™. Your participation helps optimize our delivery of energy, stabilize rates, and reduce energy. Best of all, you are saving energy dollars!
Your Enrolled Programs
Residential UtilityPRO Cool
123456789 - peaksaver PLUS has not been activated today.

Thermostat – Schedules



To change your thermostat schedule:

1. Under “Thermostat,” click on your thermostat’s name and then click on “Schedules.”
2. To set up a new schedule, click the “Create” button below the thermostat. Then, choose from one of three options: “Same schedule every day of the week,” “Weekday, Saturday, Sunday schedules” or “Different schedule each day of the week.”
3. If you want to edit an existing schedule, click on the “Edit” link, just below the thermostat.
4. On the thermostat, you can slide the bars left to right to change times for Wake, Leave, Return and Sleep. These should be set for a half an hour before you would like the temperature to reach the selected level. You can also slide the bars on each thermometer from left to right to adjust the cooling or heating temperatures. Or, you can manually input the settings and you will see the thermostat adjust accordingly. You can also choose to view temperatures in °C or °F.
5. “Recommended Settings” shows settings we recommend for comfort and cost management. If you want to redisplay or use these settings click the button.
6. Once you’ve created a schedule, enter a name in the “Schedule Name” field, then click “Save.” If you want to use this schedule immediately, click on “Send Now,” below the thermostat.

Thermostat – Manual



To temporarily change your thermostat settings:

1. Choose your thermostat name and select "Manual" from the sub-menu.
2. Select the "Mode" and "Fan" settings that you want to set.
3. Enter or select the new temperature to set. Select "Hold" to maintain this temporary setting across any program changes.
4. Click "Send" to send your settings to the thermostat.
5. You can choose "Run Program" to revert to your previous thermostat program.

Schedule Name



To change the name on your thermostat:

1. Choose your thermostat name and select “Manual” from the sub-menu.
2. Click “edit” next to the thermostat name in the red bar.
3. Enter a new name for the thermostat in the text box.
4. Click “Save.” The new name will appear under “Thermostat” in the sidebar menu.

Program – Control History



To view the control history of a program:

1. Under "Programs," click the "Control History" link.
2. Click "View Complete History."
3. Select the time period to view from the drop-down menu.

Please note: If ***peaksaver* PLUS**™ has not yet been activated, no history will appear for your thermostat.

Administration



To change your username or password:

1. Under “Administration,” click the “Change Login” link.
2. A new username can be entered in the “New Username” text box. Enter your current password and click “Save.”
3. To change your password, enter your current password, then enter your new password in “New Password” and again in the “confirm password” text boxes.
4. Click “Save.”

   Please click “Logout” in the top right corner of the window to exit the website when you are finished viewing and modifying your settings.